

Repair Parts


894-E73-317XKABCP

Hot and Cold Water Sink Faucet with Pop-up Waste


CHICAGO FAUCETS®

Geberit Group


Base Parts:



4" Wristblade Handle 317-PRJKCP




3-1/2" Rigid / Swing Gooseneck Spout GN1AJKABCP



1.0 GPM (3.8 L/min) Non-Aerating Laminar Outlet E73JKABCP



Ceramic 1/4-Turn Cartridge (pair) 1-099XKJKABNF (right) 1-100XKJKABNF (left)



For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive

Des Plaines, IL 60018

Phone: 847-803-5000

chicagofaucets.com